



User manual AXIWI® AT-350 - 6 persons two-way (duplex) communication

With the AXIWI communication system, you have to setup 1 unit as a master. The other units have to be set up as a submaster or a follower, depending if you want to be able to talk continuously or incidentally. With a submaster your speaking function is always activated. With a follower you have to manually activate and deactivate your speaking function.



In order to set up the AXIWI communication system, you have to make the following installation steps.

Before you start, first plug in the headsets.

Set up as Master

1. Push and hold the volume up **▲** button.
2. Then push the 'on/off' button (approx. 1-2 seconds) while pushing the volume up **▲** button at the same time.
3. The AXIWI unit is set up in the 'Master' mode.; the letter '**M**' appears at the left top of the display.

Set up as Submaster

1. Push and hold the volume down **▼** button.
2. Then push the 'on/off' button (approx. 1-2 seconds) while pushing the volume down **▼** button at the same time.
3. The AXIWI unit is set up as submaster; the speaking function of the AXIWI is continuously activated.

Set up as Follower

1. Push the 'on /off' button (at least 2 sec.). The AXIWI is set up as Follower;
2. With the speaking button on the front, the speaking function can be activated and deactivated. Press the speaking button briefly to activate (and again) to deactivate the speaking function.
3. When the speaking function is activated a microphone will appear in the display.

Change the channel

Press the **M**-button briefly. The channel will blink. With the up **▲** or down **▼** button you can change the channel. You confirm the channel with the M-button.

